



Jayhawk Bowling Supply

785-842-3237 · 800-255-6436

Fax: 785-842-9667

DIRECTIONS FOR ACHIEVING DESIRED PITCHES					
Display	Table Moves	Turn Crank	Thumb	Fingers	
(-) Thumb Reverse	Away	Right			
(+) Thumb Forward	Toward	Left	○ ○	○ ○	
(+) Thumb Left	Right	Toward		<u>○</u> <u>○</u>	
(-) Thumb Right	Left	Away		<u>○</u> <u>○</u>	
(+) Finger Reverse	Toward	Left	<u>○</u>	○	
(-) Finger Forward	Away	Right	○	○	
(+) Finger Left	Right	Toward			
(-) Finger Right	Left	Away			
Display	Table Moves	Turn Crank	Thumb	Fingers	
(+) Thumb Reverse	Toward	Left			
(-) Thumb Forward	Away	Right	○ ○	○ ○	
(-) Thumb Left	Left	Away	<u>○</u>	<u>○</u> <u>○</u>	
(+) Thumb Right	Right	Toward		<u>○</u> <u>○</u>	
(+) Finger Reverse	Toward	Left	○ ○	○	
(-) Finger Forward	Away	Right	○ ○	○	
(+) Finger Left	Right	Toward			
(-) Finger Right	Left	Away			

NOTE: Crank directions are for mill machines.